

TECH DATA

Technical Information Sheet



TECHNICAL DATA:

- FREEZE-THAW: Keep from freezing.
- SHELF LIFE: Six months at 70 °F
- COLOR: White
- TACK PERIOD: 30 - 60 seconds with pressure
- TYPICAL COVERAGE: 25 linear yards per gallon
- CONSISTENCY: Medium syrup

APPLICATION:

Brush or squeeze bottle.

CLEANUP:

Use water when adhesive is wet. Clean wet or dry with nonflammable solvent.

PACKAGING:

1 Quart and 1 Gallon

LIMITATIONS:

Not freeze-thaw stable. Do not store under 40 °F temperature.

CAUTION:

Use adequate ventilation. Avoid prolonged breathing of vapors. After using, be sure to wash your hands thoroughly, particularly before eating. May cause skin and eye irritation. Avoid contact with skin and eyes. Thoroughly wash exposed area with soap and water. Eyes: flush with large amounts of water, lifting upper and lower lids occasionally; call a physician immediately. Ingestion: Do not induce vomiting. Call a physician immediately. Keep container closed. KEEP OUT OF REACH OF CHILDREN. [Refer to Material Safety Data Sheet (MSDS) for further information.]

APAC 701

LATEX SEAMING ADHESIVE

QUICK DRYING • VOC COMPLAINT • NONFLAMMABLE

DESCRIPTION

Natural latex-based adhesive for bonding seams of all types of carpet except vinyl-backed. May be used to bond various types of fabrics to themselves, patches on furniture, auto upholstery, etc., coat backs of throw rugs to make them skid proof. Resistant to fungus, mildew, water and commercial carpet cleaners. 701 is specially formulated for seaming, binding, and repairing carpet. It is water-resistant, fast drying, flexible and nonflammable.



FEATURES & BENEFITS:

- Resistant to Fungus & Mildew
- Water Resistant
- Quick Drying
- Great for Carpet Repairs
- Semi-transparent when Dry
- Prevents Raveling
- Flexible

WARRANTY:

- Limited Warranty

USES:

- All types of carpet (except vinyl-backed): ActionBac®, Jute, Latex Unitary, Woven, Rubber Backed, Urethane (attached cushion)
- Direct glue and double glue applications
- Various types of fabrics, patches on furniture, auto upholstery, etc., coat backs of throw rugs to make them skid proof.

DIRECTIONS

- FOR BACK SEAMING: Spread adhesive the length of the seam. Be certain you have even coverage. Unroll seaming tape the length of seam roll and allow to dry.
- FOR SEAMING: Lay carpet face up with seam edges butted tightly. Insert paper-backed seaming tape under the carpet at the seaming area.

Apply a good quantity of 701 to the tape where it will be in contact with the back of carpet, and coat the back of the carpet liberally where it will be seamed. The double coat will insure that the carpet fibers and the tape are wet, thus a strong seam will result. Allow carpet to dry for four to five hours before installing.

- FOR SEAMING EDGING: Apply 1/8" bead of adhesive at the interface of the primary and secondary backing, work seam adhesive in with fingertip, and allow to dry before seaming with hot melt carpet seaming tape.
- NOTE: Avoid spilling adhesive on face of carpet. Repeated washing with water and detergent will remove the adhesive. Use safety solvent to clean up dried latex.

APAC

All Purpose Adhesive Company
2424 Lakeland Road • Dalton, GA 30721
800-747-APAC • Fax: 706-277-4157
www.apacadhesives.com

ASSOCIATIONS:

